


Operation

1 Operating the air shear

- This Air Shear is designed to operate on 90 PSIG. Lower pressure (below 90 PSIG) will reduce performance of the tool. Higher air pressure (over 90 PSIG) raises the performance of the tool beyond its rated capacity and could cause serious damage to the tool and the user.



2 Cutting metal and plastic

- The air shear is suitable for cutting metals and plastics up to 16 gauge.
- Hold the air shear with one hand on the handle. Place the open shear blades on the work surface. To start cutting, press the trigger lightly and then increase the trigger pressure to achieve the desired cutting speed.

